

Posición	Descripción	Cantidad	Posición	Descripción	Cantidad
A47	Blowout plate	1	A91	Combination bolt M5x35	2
A46	Wool felt	1	A90	Starter rope	1
A45	Air filter sponge	1	A89	Starter knob	1
A44	Air filter cover	1	A88	Rope jacket cushion	1
A43	Air filter knob	1	A87	Rope jacket	1
A42	Screw ST3X10	4	A86	Starter cover decoration	2
A41	Guiding plate	1	A85	Spacer nut M5	2
A40	Brand badge	1	A84	Starter cover	1
A39	Bolt M5X16	1	A83	Coil spring	1
A38	Brush 5x7x7	1	A82	Rope wheel	1
A37	Cylinder cover	1	A81	Torsion spring	1
A36	Cylinder cover decoration	1	A80	Hatchet	1
A35	Spark plug cap	1	A79	Washer 5.2X16.6X1.4	1
A34	Screw M5x14	1	A78	Bolt M5X12	1
A33	Needle bearing K101416	1	A77	Starter assy	1
A32	Piston nap	2	A76	Nut M8	1
A31	Piston pin	1	A75	Start plate	1
A30	Piston	1	A74	Oil seal 12x22x7	1
A29	Piston ring	2	A73	Right crankcase	1
A28	Washer of cylinder	1	A72	Gasket of crankcase	1
A27	Muffler washer	1	A71	Crankshaft	1
A26	Bolt M4x10	3	A70	Half-ring key 3x6x13	1
A25	Combination bolt M5x12	1	A69	Bearing 6202	2
A24	Bolt M5x50	2	A68	Lift crankcase	1
A23	Spring washer 6	2	A67	Bolt M5x20	4
A22	Washer 6	2	A66	Fuel tank support	1
A21	Muffler heat shield	1	A65	Fuel tank cap	1
A20	Muffler	1	A64	Pipe 2.5x5x100	1
A19	Spark plug	1	A63	Fuel tank	1
A18	Bolt M5x20	4	A62	Fuel filter	1
A17	Cylinder	1	A61	Fuel pipe 3.5x5.5x200	1
A16	Ignition coil	1	A60	Fuel pipe support	1
A15	Combination bolt M5x20	6	A59	Pipe 2.5x5x50	1
A14	Gasket of inlet pipe	1	A58	Clamp	2
A13	Inlet pipe	1	A57	Suction mouth	1
A12	Combination bolt M5x28	2	A56	Fuel tank assy	1
A11	Oil seal 16x30x7	1	A55	Aluminised paper	1
A10	Flywheel	1	A54	Gasket of carburetor	1
A9	Flange nut M8	1	A53	Carburetor	1
A8	Washer 8x16x1.5	2	A52	Screw ST3X8	1
A7	Clutch	1	A51	Choke lever	1
A6	Wave washer 10x16x0.5	2	A50	Air filter support	1
A5	Clutch bolt M5X24	2	A49	Choke plate	1
A4	Round pin 6x10	4	A48	Bolt M5x50	2
A3	Side cover	1			
A2	Cable cleat	1			
A1	Combination bolt M5x25	6			

