





RAPTOR LM28 - B

SPARE PARTS



ID	ERP	Name	Units
1-1	030312035	Cover plate sheet metal	1
1-2	030312036	Panel01	1
1-4	030312034	Shield cover protective net	1
2-1	030312038	Front baffle	1
2-2	030108002	LED lights	2
2-3	030404232	M3*16 SCREW	4
3-1	030312030	Frame	1
4-1	030107005	Walking motor	2
4-2	030401020	M22*1.5 lock nut	2
4-3	030312017	Output shaft	2
4-4	030405026	Deep groove ball bearing	2
4-5	030312016	Support seat	2
4-6	030420003	Oil seal	2
4-7	030312007	Drive wheel	2
4-8	030408002	Flat key	2
4-9	030404097	M8X60 Full Thread Hexagon Head	10
4-10	030402015	M14*37*3 Gasket	2
4-11	030401021	M14 lock nut	2
5	030215009	Crawler track	2
6-1	030401018	M16 nut	8
6-2	030402014	M16*30*2 FLAT WASHER	8
6-3	030312012	Load wheel dust cover 01	16
6-4	030312011	Limit block 02	8
6-5	030312010	Support roller 128_1	4
6-6	030312054	Bushing	4
6-7	030312013	Central shaft 02	4
6-8	030405027	Deep groove ball bearing	16
7-1	030404099	M10*150 hexagon head bolt with full thread	4
7-2	030404109	M10*50 hexagon head bolt with half thread	4
7-3	030312015	Tension block 01	4
7-4	030401019	M10 NUT	4
7-5	030312009	Limit block 01	8
7-6	030312008	Support roller 160	4
7-7	030312014	Central shaft 01	4
8-1	030107004	Engine	1
8-2	030404088	M10X55 Full Thread Hexagon Head	4

8-3	030404100	7-16-20*2 hexagon head bolt with half thread	1
9	030215019	Rubber handle	2
10	030312002	Electric push rod 100mm	2
11	030312001	Electric push rod 20mm	1
12	020504001	Lead-acid battery	2
13-1	030312039	Fuel tank	1
13-2	030215006	Fuel tank cap assembly	1
13-3	030404218	M6*20 hexagon head bolt with full thread	6
13-4	030215007	Fuel tank switch	1
14	030312051	Battery pressure plate	1
15	030401013	M6 lock nut	4
16	030406014	Threaded rod M6*200	2
17-1	030312037	Electric box cover	1
17-2	030101009	Antenna	1
17-3	030108001	Warning light	2
17-4	030215004	E-stop switch	1
17-5	030215003	Cable grommet	2
17-6	030106031	IEC C6 power plug	1
17-7	030404224	M6*20 hexagon head bolt with full thread	2
17-8	030402023	M6*14*1.2gasket	2
17-9	030404105	M6*12 hexagon head bolt with full thread	2
18-1	030312050	Electrical mounting plate	1
18-2	030104006	Relay	1
18-3	030215017	Storage holder	1
18-4	030104005	Circuit breaker	1
19-1	030312029	Gas strut	2
19-2	030401015	M8 lock nut	4
20-1	030409147	Hinge	2
20-2	030404223	M6*20 Hexagon Socket Head Cap Screw	4
20-3	030401016	M6 lock nut	4
21-1	030312049	PCB fixing plate	1
21-2	030109002	Drive plate	2
21-3	030102062	Main control board	1
21-4	030404230	M4*10 Hexagon Socket Countersunk Full Thread Screw	4
22-1	030107006	Generator	1

22-2	030312048	Generator base plate	1
22-3	030312019	Equal-height sleeve	1
22-4	030401014	M10 lock nut	2
22-5	030404109	M10*50 Hexagon	1
22-6	030404220	M10*150 hexagon head bolt with half thread	1
23-1	030404219	M10*30 hexagon head bolt with full thread	4
23-2	030402013	M10*30*2 Flat washer	4
24	030312047	Reinforced plate	1
25	030215008	V-belt	1
26-1	030312040	Base frame	1
26-2	030312041	Protective cover	1
26-3	030312045	Swing arm 1	2
26-4	030312044	Swing arm 2	2
26-5	030404108	M16*120 hexagon head bolt with half thread	4
26-6	030404107	M16*60 hexagon head bolt with half thread	4
26-7	030401022	M16 lock nut	8
26-8	030404103	M8*20 hexagon head bolt with full thread	11
26-9	030402024	M8 spring washer	11
27-1	020820002	Tension plate	1
27-2	030404110	M6*60 hexagon head bolt with full thread	1
27-3	030401013	M6 lock nut	1
28-1	030312042	Baffle fixing plate 1	2
28-2	030312043	Baffle fixing plate 2	2
28-3	030312004	Chain	84
28-4	030404104	M6*25 hexagon head bolt with full thread	18
29-1	030312046	Adjustment structure fixing seat	1
29-2	030312046	Adjustment mechanism swing arm adjustment mechanism swing arm	1
29-3	030404106	M6*35 hexagon head bolt with full thread	1
29-4	030401013	M6 lock nut	19
29-5	030101010	Throttle cable	1
30-1	030312005	Tool rest	1
30-2	030312006	Blade	2

30-3	030312018	blade base	1
30-4	030312052	backing plate	1
30-5	030312020	blade screw	2
30-6	030401021	M14 lock nut	2
30-7	030404101	M10*40 hexagon head bolt with full thread	4
30-8	030215025	Warning light cover	1